

# EN — ROOF FOLD®




---

## CONFIGURATION OPTIONS

### STANDARD



DEPLOYED



RETRACTED


# EN — ROOF FOLD®




---

## CONFIGURATION OPTIONS

### TRAPEZOIDAL



DEPLOYED



RETRACTED

# EN — ROOF FOLD®



---

## CONFIGURATION OPTIONS

### POSITIVE CURVE DRIVE BEAM



DEPLOYED



RETRACTED

# EN — ROOF FOLD®




---

## CONFIGURATION OPTIONS

### POSITIVE CURVE CROSS BEAM



DEPLOYED



RETRACTED

# EN — ROOF FOLD®




---

## CONFIGURATION OPTIONS

### STRAIGHT / CURVE DRIVE BEAM

DEPLOYED



RETRACTED



# EN — ROOF FOLD®




---

## CONFIGURATION OPTIONS

### GABLE AT PEAK



DEPLOYED



RETRACTED

# EN — ROOF FOLD®




---

## CONFIGURATION OPTIONS

### GABLE AT EAVES



DEPLOYED



RETRACTED